Select

Adjustable Head Rest

Recline Adjustment: Pull up on handle to adjust seat back angle.

Armrest Adjustment: Turn handle to raise or lower.

Dual Lumbar Switch: Press switch to adjust upper and lower lumbar.

Tilt Adjustment: Lift handle to tilt seat cushion and back.

Cushion Extender: Lift handle to slide the seat forward.

Height Adjustment: Pull up or down to adjust the height of the seat.

Fore/Aft Adjustment: Pull handle up to move seat forward or rearward.

Suspension Dampener: Move lever to make suspension firm(forward) or soft(rearward).

Fore/Aft Isolator: Engages the seat cushion Isolator; Down-unlock, up-locked.

Quick Down w/ Memory: Push this button down until it locks and seat will go to full down position. When the botton is released the seat will automatically return to the previous setting.